



Sensible Products for a Non-Sensible World

SenSci BlackOut® Maintenance and Directions for Use



No Lubricants Necessary

Laboratory studies and field evaluations, have indicated that very few, if any, bed bugs can escape BlackOut™ with no lubricants in the trap well. Therefore, BlackOut™ can be installed in a home without lubricants added to the trap wells.

**While its not suggested, if you're intersted in additives, such as talcom powder, visit <http://www.senscionline.com/BlackOutTalc/> or any proper usage directions.



Cleaning to Prevent Escape

BlackOut's recommended maintenance is cleaning the trap well with a microfiber cloth every 2-4 weeks to clear any dust out of the trap wells. Dust accumulation can be similar to rocks on a rock-climbing wall for bed bugs to escape. To prevent bed bugs from escaping, thoroughly clean the inner walls with a microfiber cloth.

IMPORTANT:

Only microfiber cloths should be used to reduce scratching of the trap well.



BlackOut™ Placement

Place one BlackOut™ device under each othe legs of beds, couches or other furniture of concerns for bed bugs.



If furniture leg does not fit in the center of the well of the device, place the device next to each of the legs of the furniture.



BlackOut™ Placement - Furniture

If the furniture is resting on the floor, place one BlackOut™ device every three feet on the floor around the perimeter of the furniture or at the four corners of the bed.

For an informative tutorial video on BlackOut™, visit <https://youtu.be/zgpkOlrumFw>



PO Box 5309, Trenton, NJ 08638
SENSCIONLINE.COM